


SILENT INVERTER GENERATOR USER'S MANUAL



owner's manual

Thank you for choosing our inverter generator.

This manual covers the right operation and maintenance. Before operating, please read it carefully, then you'll gain good rewards.

All technical data and drawings in this manual are consistent with the latest products while publication. As a result of revisions and other changes, the contents of this manual may be slightly different from the actual situation. Our company reserves the right to make changes at any time, without notice and without incurring any obligation, please understand.

The copyright of this instruction manual belongs to our company. No reproduction is allowed without the written consent of Our company. All rights reserved.

This manual is a permanent part of the generator set and will be resold together with the generator set if it is resold.

Safety Warning

The personal and property safety of you and others is very important. Please read carefully the extremely important safety warnings we have written in the manual and the label of the generator set.

Safety warnings can alert you to potential dangers that may harm you and others.

There are one of these three symbols : "Danger", "Warning", "Notice" in front of safety warning. Details as below:



If you do not follow the instructions, your life will be in danger or you will be seriously injured.



If you do not follow the instructions, your life will be in danger or you will be seriously injured.



If you do not follow the instructions, you will be slightly injured.

If you do not follow the instructions, your generator set and other property may will be damaged.

Content





Safety Warning	3
Content	4
1. Safety Instruction.....	6
1.1 Safety Specification.....	6
1.2 Special Request	7
2. Safety Warning Label	8
3. Components Identification	9
3.1 Components Feature	9
3.2 Control Panel	10
3.3 Type and Serial Number	11
4. Control System.....	12
4.1 Engine oil alerting system(YELLOW).....	12
4.2 Overload Indicating Light(RED)	12
4.3 AC Indicating Light(GREEN)	13
4.4 ECO Switch	13
4.5 Ground Terminal	14
5. Preparation.....	15
5.1 Fuel Oil	15
5.2 Engine Oil	16
5.3 Recoil Starter	17
5.4 Fuel Tap	17
5.5 Choke Valve	18
5.6 AC Breaker Protector	19
5.7 Ground Terminal	19
6. Generator Use.....	20


6.1 Connect to Household Power Supply.....	20
6.2 Generator Grounding	21
6.3 AC Power	21
7. Starting the Engine.....	24
7.1 Recoil Start.....	24
7.2 Electric Start	24
8. Stopping the Engine.....	27
9. Maintenance	28
9.1 Engine Oil Replacement.....	30
9.2 Air Filter Maintenance	31
9.3 Spark plug.....	32
10. Storing.....	33
11. Troubleshooting	34
12. Electrical Diagrams	35
13. Technical Specifications	36

1. Safety Instruction

1.1 Safety Specification

Please read and be well known about the manual before operating. Familiarity with the safe operating procedures of generators can help you avoid accidents.

	
Don't use it indoor.	Don't use it in damp environment.
	
Do not connect directly to household appliances.	Don't smoke while adding fuel oil.



1.2 Special Request

- Electrical equipment includes unexposed wires and plugs.
- The protecting breaker should be matched with generator. The application parameters and performance should be totally matched if changing.
- Well grounded before using
- If need extension wire, it must meet the requests as below: 4mm^2 , length no more than 100m.

2. Safety Warning Label

Please read the manual carefully before using.

Safety warning label



WARNING



Do not connect to a building's electrical system.



Let the generator cool before storing.

Gasoline is explosive and flammable, please use the generator outdoor.



Do not expose the generator to rain, moisture or snow.



Not to refuel when operating

Check that there is not any fuel spilling or fuel leakage.



Exhaust gas is poisonous;

Do not operate in an unventilated area [Carbon monoxide (CO) danger]



Read the operator's instruction manual.



WARNING





Hot exhaust can burn you. Stay away if engine has been running.



3. Components Identification


3.1 Components Feature



3.2 Control Panel


(Factory will adjust the panel according to different configuration.
Please note that subject to change without prior notice.)

H4500iS/ H4500iE



1	Digital meter	6	DC socket
2	ECO(Economy system control)	7	USB
3	Reset button	8	Parallel socket
4	AC protector	9	AC socket
5	DC protector	10	Ground terminal


3.3 Type and Serial Number



4. Control System

4.1 Engine oil alerting system(YELLOW)

The engine oil protection system will stop the engine automatically, and the engine oil indicating lights, while the oil in crankcase is under safe line; Fill the engine oil to the oil level, it can be restart again.



If the engine oil alerting light flashes for few seconds, it means the oil capacity is insufficient. Refill the oil and restart the engine.



4.2 Overload Indicating Light(RED)

When the overload indicating light is on, the generator detects that the output of the phase-side electrical equipment has been overloaded, causing the converter to overheat or the AC voltage to rise. Then the AC protector works and stops the generator to protect the generator and the equipment which connects with it. The AC indicating light(GREEN) is off, but overload indicating light (RED) is on, engine will not stop working.

While the overload light is on, and the generator has no output, please take following measures:

1. Turn off the connected electrical equipment and stop engine.
2. Reduce the total power rate of connected electrical equipment within the rated output range.
3. Check whether the cool air inlet is blocked by foreign matters and whether the relevant control parts are abnormal. If there is any problem, remove it immediately.
4. Restart the engine after checking.

Notice: When using the electrical equipment with high starting current(like compressor and sinking pump...), the overload indicating light may will flash for few seconds. But this doesn't belongs to troubles as aforementioned.

4.3 AC Indicating Light(GREEN)


The AC indicating light will be on while the engine starts and keep normal output.



4.4 ECO Switch

① "ON"

While the ECO switch is on position of "ON", the equipment will control rotating speed according to the connected load, so as to get good fuel oil consumption and low noise.




② "OFF"

While the ECO switch is on position of "OFF", whether it connects with load, the engine also runs at a rated rotating speed. (3600r/min)

NOTICE: Cause it needs heavy start current, ECO switch must be off while using compressor.

4.5 Ground Terminal

The ground terminal is connected to the ground wire to prevent electric shock. The generator should be connected to ground while the electrical equipment connecting to ground.





Ground terminal

5. Preparation

5.1 Fuel Oil



- Fuel oil is flammable and toxic. Please read the safety instruction carefully before refueling.(See Page 7 for details.)
- Do not fill the tank with too much oil, or the oil will overflow when the tank gets warm.
- After refueling, make sure the fuel tank cover is tightened.



- To avoid damage the plastic outer case, please wipe off residual gasoline with a clean, soft cloth after refueling.

- You must use unleaded gasoline. The leaded one would damage the internal parts of the engine.

Suggestion: unleaded gasoline



Fuel oil tank capacity: 12.5L

5.2 Engine Oil




The generator is not injected with engine oil when leaving the factory. Please do not start it before injecting enough engine oil.

1. Please place the generator on the horizontal plane.
2. Turn the knob ① to "ON", and put down oil maintenance door ②.
3. Open the fuel cap ③.



4. Refuel a recommended amount of oil and tighten the cap.
5. Replace oil maintenance door and turn knob to "OFF" position.




Recommended oil: SAE SJ 10W-40

Recommended oil grade: API standard SE or higher grade

Engine oil capacity: 0.6L

5.3 Recoil Starter

Pull the starter handle up gently until resistance is felt, then pull it out suddenly.




Recoil Starter

5.4 Fuel Tap


Fuel tap is a device that controls the flow of fuel from the tank to the

carburetor. Please make sure it is on position of "OFF" after stop working.




5.5 Choke Valve

Choke valve is used to provide a rich mixture of oil to a gasoline engine when the cold engine is started. When the cold gasoline engine starts, rotate the start switch to put the start button in the "START" position. When the gasoline engine starts up warmly, the starting switch is rotated to put the starting button in the "RUN" position.



5.6 AC Breaker Protector

Overload current can turn off the breaker protector automatically. The load shortened and overload should be avoided. If the breaker protector closed automatically, please must test the loading before opening.



5.7 Ground Terminal

Ground terminal connects the earth line for prevention of electric shock. When the electric device is grounded, be sure to ground the generator also.



6. Generator Use


- Applicable temperature: $-5^{\circ}\text{C} \sim 40^{\circ}\text{C}$
- Applicable humidity: below 95%
- Applicable altitude: areas below 1000 meters (If you operate your engine at altitudes above 1000 meters, reduce the engine power or modify the carburetor by contacting the suppliers.

6.1 Connect to Household Power Supply




When the generator is connected to the household power supply as a standby power supply, it should be connected by a special electrician or someone familiar with the electricity.

After connecting the load to the generator, carefully check whether the electrical connection is safe and reliable. If there is incorrect electrical connection, it may cause generator damage, combustion or fire.



6.2 Generator Grounding

In order to prevent the generator from being damaged by electric shock or misuse of inferior electrical appliances, the generator should be grounded by a good insulated conductor.




6.3 AC Power

Before starting the generator, it should be confirmed :

The total power of all electrical appliances (the sum of resistance, capacitance and inductive load) shall not exceed the rated power of the generator.











Overload operation will lead to generator stalling or greatly shorten the life of the generator. If there are multiple loads or electrical equipment connected to the generator set, please keep in mind that: first turn on the highest starting load, then turn on the second, and finally turn on the



lowest starting load.

Generally speaking, capacitive and inductive loads, especially motor drive devices, will cause large starting current when starting.

The following table is for your reference when connecting these electrical appliances to the generator set.

Type	Power		Typical Device	Example		
	Max.	Rated		Device	Max.	Rated
<ul style="list-style-type: none"> ● Lamp ● Heating devices 	*1	*1	100W  lamp  TV	100W  lamp	100VA (W)	100VA (W)
<ul style="list-style-type: none"> ● Fluorescent lamp 	*2	*1.5	40W  Fluorescent lamp	40W  Fluorescent lamp	80VA (W)	60VA (W)
<ul style="list-style-type: none"> ● Electrical devices 	*3-5	*2	 Fridge 150W  Fan	150W  Fridge	450-750VA (W)	300VA (W)

This engine may require a high altitude carburetor kit to ensure correct engine operation at altitudes above 1000 meters. The performance of a gasoline engine can be improved by replacing a slightly smaller main nozzle on the carburetor or by adjusting the adjustment screw. If you often use generators in areas over 1000 meters, you can buy special high-altitude components for replacement. Otherwise, reduce load power when using generator.

Even with a suitable carburetor, the power of the gasoline engine will decrease by about 3.5% for every 300 meters above sea level. If the carburetor is not replaced properly, the decline will be even greater.




If carburetors suitable for use at high altitudes are equipped with gasoline engines at low altitudes, excessive lean mixture will reduce the output power of gasoline engines, cause overheating and even cause serious damage.

7. Starting the Engine

7.1 Recoil Start

- 1) Remove all loads from the output end.
- 2) Rotate the start switch to place the start button in the "start" position.
- 3) Turn the AC BREAKER to "OFF"




When the gasoline engine starts in the hot engine status, please rotate the start switch to place the start button in the "running" position.

- 4) Pull the recoil starter slowly until it is engaged, then pull it briskly.
- 5) After starting the engine, rotate the engine switch to place the start button in the "run" position.
- 6) To use electrical equipment, AC circuit breaker protector should be placed in "on" position.

7.2 Electric Start

- 1) Remove all loads from the output end.
- 2) Rotate the start switch to place the start button in the "start" position.
- 3) Turn the AC BREAKER to "OFF"



When the gasoline engine starts in the hot engine status, please rotate the start switch to place the start button in the "running" position.

- 4) Press the "ON" button.
- 5) After starting the engine, rotate the engine switch to place the start button in the "run" position.
- 6) To use electrical equipment, AC circuit breaker protector should be placed in "on" position..



Don't turn the generator switch to the electric starting position for more than 5 seconds, otherwise the starting motor will be damaged. If starting is unsuccessful, 10 seconds should be interval between

multiple starting.

If the speed of the starting motor decreases more after a period of time, it means that the battery should be charged.

8. Stopping the Engine

- 1) Turn the the ECO switch to “OFF” ;
- 2) Turn off the AC Breaker ;
- 3) Turn the engine switch to “OFF”;
- 5) Disconnect any electric devices.



To stop the engine in an emergency, turn the Engine Switch to the “OFF” position.

9. Maintenance

Safety is an obligation of the owner. Periodic inspection, adjustment and lubrication will keep your generator in the safest and most efficient condition possible. In order to keep the engine in good condition, you must check and maintain it regularly. Please follow the schedule below.

Maintenance Schedule

Regular Service <u>Period</u> (3)		Each use	First	Every 3	Every 6	Every
Item			month or 10 hrs	months or 50 hrs.	months or 100hrs	2 years or 300 hrs.
Engine oil	Check level	☉				
	Replace		☉	☉	☉	
Air cleaner	Check	☉				
	Clean			☉(1)		
	Replace			☉		
Spark plug	Check & adjust			☉		
	Replace					☉
Spark arrester	Clean		☉	☉	☉	
Valve Clearance	Check & adjust					☉(2)
Fuel tank & filter	Clean				☉	
Cylinder Head	Clean	After every 300 hrs(2)				
Fuel hose	Check	Every 2 years (Replace if necessary)(2)				

(1) Maintenance more frequently when used in dusty or unusually wet areas.

(2) These items should be serviced by your servicing dealer, unless you have the proper tools, data and technical skills.



- If you often work at high temperature or high load, you should replace the engine oil every 10 hours.
- If you work in dusty or harsh environments, clean the filter element of the air filter every 10 hours. If necessary, air filter elements should be replaced every 25 hours.
- The inspection period and time should be maintained on a first-come basis.
- If the maintenance cycle has passed, the maintenance should be carried out as soon as possible according to the above table.




- Stop the engine before starting maintenance work. The engine should be placed horizontally. To prevent the engine from starting, separate the spark plug cap from the spark plug.
- Never operate the engine in a closed area or it may cause unconsciousness and death within a short time. Operate the engine in a well ventilated area.

9.1 Engine Oil Replacement

Please drain the engine oil after starting the gasoline engine. It can ensure that the oil is discharged quickly and cleanly.

- ① Remove oil level gauge and then turn open the oil drain bolt and drain the oil.
- ② Install the oil drain bolt and tighten it.
- ③ Add engine oil to the correct level.
- ④ Install the oil level gauge.

Engine oil capacity: H4500iS / H4500iE 0.6L



Long-term and frequent skin exposure to engine oil may lead to skin cancer. Soap and water are recommended to wash the oil-exposed skin thoroughly and immediately.

To protect environment, please properly deal with the waste oil after use. We strongly recommend that: put waste oil into sealed containers (bottle or cans), and then send it to your local service station or waste oil recycling center. Keep in mind: don't throw it into the garbage dump or dump it on the ground or in the ditch.

9.2 Air Filter Maintenance

Dirty air filters will affect the flow of air into carburetors. To prevent carburetor breakdown, air filters should be regularly maintained. If it is used in dusty environment, it should be maintained more frequently.



Cleaning the filter element with gasoline or flammable solvents may cause fire or explosion. Please use soapy water or non-flammable solvent to clean the filter element.




It is strictly forbidden to start the generator without air filter, otherwise it will lead to rapid wear and tear of the gasoline engine.

1) Open the connecting button of the air filter cover and open the air filter cover. Check the filter element and ensure it's in good condition and clean.

2) If the foam filter is dirty, please clean it. Wash in hot water with household detergent or in non-flammable or high flash solvent. Then rinse with clean water and squeeze. Then drop a few drops of oil and squeeze evenly.

3) Fill in the filter element and cover the air filter cover.




9.3 Spark plug

Please replace the spark plug according to the original type: F7TC

- 1) Remove the spark plug cap.
- 2) Use the spark plug socket wrench to remove the spark plug.
- 3) Visually inspect whether the spark plug insulator is damaged.
Replace the spark plug if it is damaged.
- 4) Measure spark plug clearance with thickness gauge. Bend the side electrodes to adjust the clearance. The clearance shall be between 0.70 and 0.80mm.
- 5) Check that if the spark plug gasket is in good condition.

Install the spark plug, tighten it with the spark plug socket wrench, and press down the spark plug gasket. Cover the spark plug cap.



Please use spark plugs with appropriate calorific value.

10. Storing



To avoid combustion or misfire due to contact with high-temperature components of the generator, the generator must be cooled before packaging and storage.

If long-term storage is required, please make sure the storage area is clean and dry.

1) Drain fuel from the fuel tank.Clean the fuel filter, O - ring seal and precipitation cup after the assembly.Unscrew the carburetor drain bolt, drain the fuel from the carburetor entirely, then reinstall and tighten the carburetor drain bolt.



In ordinary circumstances, gasoline is flammable and explosive. Please discharge oil in well-ventilated condition after stop. No fireworks during oil discharge.

2) Unscrew the oil gauge and Oil drain bolt on the crankcase, and drain the oil in the crankcase. Then tighten the drain bolts, add new oil to the upper limit, and then install the oil gauge.


3) Remove the spark plug and pour a tablespoon of clean engine oil into the combustion chamber. Turn the crankshaft several times to distribute the oil. Reinstall the spark plugs.

4) Gently pull the starting handle until resistance is felt, leaving the inlet and exhaust doors close.


5)Place the generator set in a clean and dry area.

11. Troubleshooting


Engine can't be started:



No voltage



12. Electrical Diagrams



13. Technical Specifications

	Model	H4500iS	H4500iE
Engine	Engine Type	Single Cylinder, 4 Stroke, Air Cooling, OHV 25°	
	Displacement(cc)	225	
	Ignition System	CDI	
	Starting Type	Recoil Start	Electric Start
	Oil Capacity(L)	0.55	
Generator	Fuel tank Capacity(L)	12.5	
	Frequency(Hz)	60	
	Phase	Single	
	Rated Voltage(V)	120	
	Rated Power(kW)	3.2/3.5	
	Max. Power(kW)	3.6/4.0	
	DC Output	12V/8.3A	
	Dimension (L*W*H)(MM)	595*440*510	

